



FIRE PIT

MINICKMATERIALS.COM

Materials Needed:

☐

5/8" Chips

☐

Stone or Keystone retaining wall blocks

☐

Alliance Gator Block Bond

☐

Decorative chips or stones to lay inside of pit (optional)

** Note: Be careful what you choose to fill your fire pit with. Anything that is touching direct flame should not have been sourced from water (ie beach pebbles, river rock, anything round) as these might have pockets of air/water that can pop.*

INSTRUCTIONS

- 1 Measure out and mark dimensions of wall
- 2 Dig circular trench deep enough to bury half of your block, plus a thin layer of gravel. Make trench slightly wider than your wall block or stone
- 3 Add 5/8 chips to trench
- 4 Bury base blocks halfway deep in trench and surround with 5/8" chips
- 5 Apply Gator block bond and adhere the next layer so that the seams of the top row are offset from the ones below.
- 6 Repeat until desired height.
- 7 Lay down layer of your 5/8" chips or other decorative rock on the inside of the pit. (Especially helpful if you're building on soil)



Disclaimer: This is just one way to create a simple version of this project, and is not the only way to do so. Consider doing your own research, or watching instructional videos for more detailed instructions.



Scan to explore our pricing list.

