

## KOI POND MINICKMATERIALS.COM

Materials	Washed fill sand	Accent boulders
Needed:	Border stone (can be chopped or boulders)	(Optional) Boulder drilled for waterfall (ask about drilling
	River rocks	options)

## **INSTRUCTIONS**

- Measure and dig our area for pond
- 2 Lay down layer of sand in the bottom
- 3 Add waterproof pond liner (Sold Elsewhere)
- 4 Place fountain mechanism
- Add border stones around perimeter of pond
- 6 Place desired river rocks along the bottom and sides of the pond. Use stones 2-4" or larger for weight and smaller stones to fill in gaps.
- 7 Add any other decorative rocks or boulders around perimeter of pond for accents



Disclaimer: This is just one way to create a simple version of this project, and is not the only way to do so. Consider doing your own research, or watching instructional videos for more detailed instructions.



