

MATERIALS NEEDED:

- ☐ 5/8" Chips
- ☐ Rich Mix soil *(or whichever works best for your project)*
- ☐ Chopped stone or Keystone retaining wall blocks

INSTRUCTIONS

- 1** Measure out and mark dimensions of wall. (A water hose works well as an easy measuring tape hack)
- 2** Dig trench deep enough to bury half of your block, plus a thin layer of gravel. Make trench slightly wider than your wall block or stone
- 3** Add 5/8 chips to trench
- 4** Bury base blocks halfway deep in trench and surround with 5/8" chips
- 5** Compact chips to stabilize
- 6** Stack next layer of blocks 1/2" - 1" back
- 7** Fill 3-4" behind block with 5/8" chips for extra stability, compacting lightly
- 8** Repeat steps 6 and 7 to desired height. Fill as you go with Rich Mix soil to support 5/8" chips



Disclaimer: This is just one way to create a simple version of this project, and is not the only way to do so. Consider doing your own research, or watching instructional videos for more detailed instructions



Scan to explore our pricing list.

